

# **Cell Cleaning Instructions**

## **Instructions for Cleaning your electrolyzer Without disassembling it.**

**Your first step is to empty all of the old electrolyte from your system. Then you want to mix the following ingredients with 1 liter of HOT tap water.**

**4 Tbsp Heaping of Iodized table salt**

**2 Tbsp Heaping of Citric Acid**

**If you system requires more than 1 liter of solution to operate, mix the appropriate amount needed in the same ratios.**

**Pour the mixture into your system, and then run your system at full amperage that it will draw for 5 minutes, or until the mixture turns almost Black.**

**Empty the system and thoroughly rinse with cold tap water several times or until no discoloration or carbon particles are present in your rinse. Then rinse it one more time, but this time with distilled water.**

**Refill your system with a fresh mixture of electrolyte and you are once again on your way enjoying your fuel savings.**

**D&N Automotive Engineering  
Jim Falls WI.**